COMPUTER SYSTEM SERVICING NC II

COC 2 (SETUP COMPUTER

NETWORKS)





PREPARED BY:


Talipan National High School

Table of Content

C	<u>_</u>	n	t	6	n	t	c
$\mathbf{\sim}$	v			C	11	. L	◡

COC 2 SETUP COMPUTER NETWORKS	3
SERVER COMPUTER USING BOOTABLE USB	3
CREATE AN IP ADDRESS IN WORKSTATION TO ACCESS INTERNET USING	
ROUTER AND HUB	4
Go to computer workstation	4
Go to computer server	5
CREATE AN IP ADDRESS IN WORKSTATION TO ACCESS INTERNET USING	
ACCESS POINT AND HUB	6
Go to computer workstation	6
Go to computer server	7
Connecting Workstation to Server	8

COC 2 SETUP COMPUTER NETWORKS



ROUTER

SWITCH HUB [] FORMATTING

SERVER COMPUTER USING BOOTABLE USB

- 1. Insert USB
- 2. Turn on computer
- 3. Press F12
- 4. Click USB device
- 5. Press any key to boot from USB
- 6. Click next
- 7. Click install now
- 8. Click windows 2008 R2 server standard x64
- 9. Click next
- 10. Check I accept the license terms
- 11. Click next

- 12. Click custom: Install windows only (advanced)
- 13. Click drive 0 partition 1: system reserved
- 14. Click delete
- 15. Click ok
- 16. Click drive 0 partition 2
- 17. Click delete
- 18. Click ok
- 19. Click drive 0 partition 3
- 20. Click delete
- 21. Click ok
- 22. Click new
- 23. Click backspace to delete
- 24. Enter the desired number 75000
- 25. Click apply
- 26. Click drive 0 unallocated space
- 27. Click new
- 28. Click apply
- 29. Click drive 0 partition 2
- 30. Click next then wait
- 31. Computer will restart
- 32. Wait to complete installation
- 33. Computer will restart again
- 34. Click begin install
- 35. Click ok
- 36. Create new password, P@SSWORD12345
- 37. Click ok

CREATE AN IP ADDRESS IN WORKSTATION TO ACCESS INTERNET USING ROUTER AND HUB

Go to computer workstation

- 1. Click start
- 2. Type cmd
- 3. Type ipconfig
- 4. Click Google chrome
- 5. Type the IP address in the Google for example 192.168.100.101
- 6. Click enter
- 7. Write admin in the username
- 8. Write admin in the password
- 9. Click log in
- 10. Change the Wireless Network Name (SSID) to your surname
- 11. Click apply then wait
- 12. Write admin in the username again
- 13. Write admin in the username again
- 14. Click network setting

- 15. Click LAN/DHCP server
- 16. Change LAN IP in your desired IP address for example 192.168.50.51
- 17. Click apply then wait
- 18. Click internet icon
- 19. Click open network and sharing center
- 20. Click change adapter setting
- 21. Click local area connection
- 22. Right click disable then enable
- 23. Go to cmd then type ipconfig for checking
- 24. Click internet icon
- 25. Click open network and sharing center
- 26. Click change adapter setting
- 27. Click local area connection
- 28. Right click then click properties
- 29. Click Internet Protocol Version 4 (TCP/IPv4)
- 30. Click properties
- 31. Click use the following IP address
- 32. Type your desire IP for example 192.168.50.6 for workstation
- 33. Click subnet mask 255.255.255.0
- 34. Click default gateway then type 192.168.50.51
- 35. Click preferred DNS server then type 192.168.50.51
- 36. Click ok then click close
- 37. Right click local area connection
- 38. Click disable and enable
- 39. Go to cmd and type ipconfig for checking
- 40. Go to Google chrome then type for example youtube

Go to computer server

- 1. Click start
- 2. Type cmd
- 3. Type ipconfig
- 4. Click internet icon
- 5. Click open network and sharing center
- 6. Click change adapter settings
- 7. Click local area connection
- 8. Right click properties
- 9. Click Internet Protocol Version 4 (TCP/IPv4)
- 10. Click properties
- 11. Click use the following IP address
- 12. Click IP address then type for example 192.168.50.7 for server
- 13. Click subnet mask 255.255.255.0
- 14. Click default gateway then type for example 192.168.50.51
- 15. Click preferred DNS server then type for example 192.168.50.51
- 16. Click ok then click close
- 17. Right click local area connection
- 18. Click disable then enable
- 19. Go to cmd and type ipconfig for checking

20. Go to internet explorer then type for example youtube

CREATE AN IP ADDRESS IN WORKSTATION TO ACCESS INTERNET USING ACCESS POINT AND HUB

Go to computer workstation

- 1. Click internet icon
- 2. Click open network and sharing center
- 3. Click change adapter settings
- 4. Right click local area connection
- 5. Click properties
- 6. Click Internet Protocol Version 4 (TCP/IPv4)
- 7. Click properties
- 8. Click obtain and IP address automatically
- 9. Click obtain DNS server address automatically
- 10. Click ok
- 11. Right click local area connection
- 12. Click disable then enable
- 13. Click start
- 14. Type cmd
- 15. Type ipconfig
- 16. Go to goggle chrome
- 17. Type the default gateway of access point for example 192.168.20.21
- 18. Then enter
- 19. Click login
- 20. Click wireless
- 21. Write your first name in the Name (SSID)
- 22. Click apply
- 23. Click setup
- 24. Click local network
- 25. Change IP address to your desired for example 192.168.35.36
- 26. Click apply changes
- 27. Click ok
- 28. Click please click 192.168.35.36 to continue configuration
- 29. Click internet icon
- 30. Click open network and sharing center
- 31. Click change adapter settings
- 32. Click local area connection
- 33. Click disable then enable
- 34. Go to start
- 35. Type cmd
- 36. Type ipconfig for checking
- 37. Click internet icon

- 38. Click open network and sharing center
- 39. Click change adapter settings
- 40. Click local area connection
- 41. Click properties
- 42. Click Internet Protocol Version 4 (TCP/IPv4)
- 43. Click properties
- 44. Click use the following IP address
- 45. Click IP address for example 192.168.35.6
- 46. Click subnet mask 255.255.255.0
- 47. Click default gateway then type 192.168.35.36
- 48. Click preferred DNS server then type 192.168.35.36
- 49. Click ok
- 50. Click close
- 51. Right click local area connection
- 52. Click disable then enable
- 53. Go to start
- 54. Type cmd then ipconfig for checking
- 55. Go to google chrome then type for example yahoo

Go to computer server

- 1. Click start
- 2. Type cmd
- 3. Type ipconfig
- 4. Click internet icon
- 5. Click open network and sharing center
- 6. Click change adapter settings
- 7. Click local area connection
- 8. Click disable then enable
- 9. Click properties
- 10. Click Internet Protocol Version 4 (TCP/IPv4)
- 11. Click properties
- 12. Click obtain an IP address automatically
- 13. Click obtain DNS server address automatically
- 14. Click ok
- 15. Click close
- 16. Click local area connection
- 17. Click properties
- 18. Click Internet Protocol Version 4 (TCP/IPv4)
- 19. Click properties
- 20. Click use the following IP adress
- 21. Click IP address for example 192.168.60.7
- 22. Click subnet mask 255.255.255.0
- 23. Click default gateway 192.168.60.61
- 24. Click preferred DNS server 192.168.60.61
- 25. Click ok
- 26. Click close
- 27. Right click local area connection

- 28. Click disable then enable
- 29. Go to cmd
- 30. Type ipconfig for checking
- 31. Go to internet explorer browse application

Connecting Workstation to Server

- 1. Click internet icon
- 2. Click open network and sharing
- 3. Click windows firewall
- 4. Turn off windows firewall
- 5. Click ok
- 6. Go to start
- 7. Type cmd
- 8. Type ipconfig
- 9. Type ping ip address of workstation 192.168.60.6
- 10. Type ping ip address of workstation 192.168.60.7